

Protemp Instructions Single Crown Interim

Jr. Prosthodontic
Clinic

Place material in matrix of single crown (note the time starting)

Place matrix on prepared tooth

Wait about 2-2.5 minutes

Remove from the teeth

Let it finish setting on the bench top until set (about 5 minutes after mixing)

